

RJ-472-08 USER GUIDE



Version 1.0

2023/2/24

1 Table of Contents

1	Table of Contents	2
2	Introduction	3
2.1	Overview.....	3
2.2	Key Features	4
2.3	SAS Topology	5
3	System Interface.....	8
3.1	Overview.....	8
3.2	Front Panel	8
3.2.1	LED.....	9
3.2.2	Button Control.....	9
3.2.3	Advance Button Control	10
3.2.4	Buzzer	10
3.3	Rear Panel.....	10
3.4	Bridge Expander Module.....	11
3.5	Edge Expander Module	15
4	Command Line Interface (CLI)	16
4.1	help	16
4.2	rev	17
4.3	showmfg.....	18
4.4	sasaddr	18
4.5	date	19
4.6	showlogs.....	20
4.7	clearlogs	20
4.8	showpost	20
4.9	sesinfo	21
4.10	sensor	22
4.11	hdd	23
4.12	console	24
4.13	bpsys	25
4.14	ipconfig.....	30
4.15	fdl	33
4.16	tftpfdl	34

2 Introduction

2.1 Overview

In-Win's RJ-472-08 typically refers to a JBOD enclosure that is designed to support a large number of drives in a relatively small space, thereby achieving a high storage density. RJ-472-08 is often used in data centers and other environments where there is a need for large amounts of storage in a compact form factor.

RJ-472-08 JBOD System is a high performance, reliable storage system with sensors to monitor system health and high-density 4U 72-bay (hot-swappable 3.5-inch drive bays) enclosure and supports SAS3 and SATA3 interfaces. We provide state-of-the-art management functionality for users to monitor and manage JBOD systems efficiently and flexibly. Users can manage JBOD systems through serial port and/or Ethernet according to the system configuration on the system.

RJ-472-08 redundancy can be achieved in several ways, including:

- Redundant Power Supplies: be equipped with two power supplies, which are connected in such a way that if one power supply fails, the other(s) will continue to power the system.
- Redundant Fans: to ensure proper cooling of the drives and other components, RJ-472-08 has been equipped with multiple fans. If one fan fails, the other(s) can continue to provide cooling.
- Redundant Expanders: provide failover in the event of a expander failure.
- Redundant Data Paths: multiple data paths may be available, which can help ensure data availability in the event of a path failure.

By implementing redundant features, RJ-472-08 can provide a higher level of availability and reduce the risk of data loss due to hardware failure and be configured with optional dual-port 12Gb/s SAS3 expansion modules for additional connectivity




FIGURE 1 RJ-472-08 INTERNAL BACKPLANES

Figure 1 depicts the internal boards system. The backplanes, front panel and power suppliers are shared by primary (BRIDGE-P, EDGE1-P, EDGE2-P and EDGE3-P) and secondary domain (BRIDGE-S, EDGE1-S, EDGE2-S and EDGE3-S). The secondary domain is optional for redundant applications.

2.2 Key Features

- Reliable High Data Rate Support (up to 12Gbps)
 - SAS3 12Gbps support and SATA3 6Gbps support to provide a reliable high-performance data rate.
- Dual SAS3 Domain Support
 - System can accommodate dual domain expanders to support data redundancy capability.
- Power Redundancy
 - System can accommodate 2 sets of power modules as redundancy. Either power module could work independently while the peer is out of order or not selected.
- Hot-swappable Modules
 - The PSUs are hot-swappable. System can keep operating during PSU replacement.

- The fan modules are hot-swappable. System can keep operating during fan module replacement.
 - The HDDs are hot-swappable. No need to shut down the system for HDD installation and/or replacement when needed.
- TCP/IP Network Support
 - Support ethernet 10/100/1000Mb TELNET/TFTP/HTTP network. User can use ethernet port to enter console and control the system.
- Faulty System Alarm
 - The Faulty System red LED indicator on the front panel illuminates along with a beeping sound while there is faulty part(s) in the system. The buzzing alarm can be muted by pressing the mute button on the front panel.
- Smart Fan Control
 - The fan modules possess a smart control feature set by the providing seven levels of speed RPM according to the detected system temperature.
- Zoning
 - This system support feature dividing disk drives into two or three different groups depending on the system preference. Each group can own users-configurable number of HDDs independently. This feature enables single JBOD to serve multiple hosts.
- Cascading
 - There are cascading ports for cascading another JBOD system to expand disk space when more space is required

2.3 SAS Topology

Tree topology reduces the number of cascade levels (or hops), avoiding or reducing the unfair arbitration that can affect the far-end devices in cascade topology. RJ-472-08 uses tree topology to reduce the number of cascade levels, avoiding or reducing the unfair arbitration. There are 4 expanders to extend the number of devices in a SAS domain. Bridge expander is the root and two edge expanders cascaded. Figure 2 depicts the topology.




FIGURE 2 RJ-472-08 SAS TOPOLOGY

RJ-472-08 can support path redundancy applications. It constructs path-redundant topologies using multi-ported devices as the Figure 3 illustrates. This topology is suitable for high-availability systems since it can fail over to a different path when one path fails.




FIGURE 3 REDUNDANT SAS SYSTEM

RJ-472-08 system is a 72-bays redundant JBOD system. There is a SAS-3 path-redundancy topology and is suitable for high availability system. Each SAS-3 domain has four expanders. Connecting HDD expander is called **edge** expander. Bay 1~24 drivers are controlled by **edge1**,

25~48 are controlled by **edge2** and 49~72 are controlled by **edge3**. Bridge expander connects three edges (downstream) and RAID or HBA card (upstream from host side).

Figure 4 and 5 show examples of the RAID application view with 15 HDDs case. RJ472Edge1P expander has slot 4, 5, 20 and 21 SAS hard disks installed. RJ472Edge2P expander has slot 28, 32, 33, 40, 46 and 47 SAS hard disks installed. RJ472Edge3P expander has slot 52... SAS hard disks installed.




FIGURE 4 MEGARAID EXAMPLE




FIGURE 5 LSI STORAGE AUTHORITY EXAMPLE

3 System Interface

3.1 Overview

The RJ-472-08 system components includes:

- Front panel with power, ID, and mute buttons and HDD status, system status and ID LED.
- Rear side with fan, bridge expander and CRPS modules
- Inside of the chassis with edge expander modules, HDD trays and other backplanes.

3.2 Front Panel

Figure 6 shows the buttons, LEDs detail on front panel.




FIGURE 6 FRONT PANEL DETAIL

3.2.1 LED

The system is equipped with LEDs to provide status information for indicating component current state.

Power LED (blue color)

- Power is applied to the system(PSU). LED is illuminated when system is in operating.

Bay LED (dual color)

- Indicates hard disk current state. There are dual color LED that blue is used for operational and red is used for warning, error or failure.
 - Blue LED steady ON – hard disk is installed and powered
 - Blue LED in 4 Hz blinking – hard disk is accessed or in activity
 - Red LED steady ON – hard disk is failed
 - Red LED in 0.5 Hz blinking – hard disk is identified (LOCATE)
 - Red LED in 1 Hz blinking – hard disk is in RAID rebuild state

Status LED (red color)

- System current status
 - Steady ON – System overheats
 - 1 Hz blinking – System fans in error condition

ID LED (green color)

- Push button and turn on to identify the enclosure

3.2.2 Button Control

There are three push-buttons on front panel and two push-buttons on rear side (on bridge expander module).

Power button

- The button is for applying or removing power from the power supply to the system
 - Turn on – Press and hold for more than 3 seconds to power on system
 - Turn off – Press and hold for more than 3 seconds to shutdown system

ID button

- Press the button to toggle the ID LED ON and OFF

Mute button

- Press the button to toggle the buzzer beeping or silence

3.2.3 Advance Button Control

Feature	Description
Auto Power-ON	Press ID + Power buttons simultaneously to toggle this feature. Power LED blinks when this feature is engaged.
Cooling Mode	Press and hold ID button for more than 5 seconds to change mode in turns. There are three fan cooling modes to setup - quiet, normal, aggressive . Default is normal mode. ID LED blinks when cooling mode is engaged.
Mute Mode	Press and hold Mute button for more than 5 seconds to toggle mute feature. Status LED blinks when feature engaged.

3.2.4 Buzzer

The buzzer is to notify system warning states

System Status	Description
Fan Error	0.25s beep and 1.75s silence repeatedly. (slow beeps)
Thermal Error	0.25s beep, 0.25 silence, 0.25 beep and 1.25s silence repeatedly. (fast beeps)
Fan & Thermal Error	Alter 'Fan Error' and 'Thermal Error' repeatedly
PSU Error	continuous beep

3.3 Rear Panel




FIGURE 7 BACKSIDE DETAIL

Fan modules, bridge expanders and PSU modules can be plug-in/out on the backside (rear-side). Figure 7 depicts the location of the components.

3.4 Bridge Expander Module




FIGURE 8 BRIDGE EXPANDER MODULE

Bridge expander module (Figure 8) is the main component that controls and manages the RJ-460-08 JBOD system. Users can use ethernet or RS-232 console cable to connect to the bridge module using telnet or some console applications to command it by CLI.

Host port (SFF-8644)

- External uplink port
- RAID or HBA card connect to the bridge module
- There are 4 ports (Host1, Host2, Host3 and Host4) for host connection

Expansion port (SFF-8644)

- External downlink port to cascade another expander

Status LED

- Works like front panel status LED
- Indicates the system current state
 - Steady ON – the system overheats
 - 1 Hz blinking – the system fans in error condition

Port LED

- There are Host1, Host2, Host3, Host4 and Expansion port LEDs
- Illuminated LED Indicates host port connection (from RAID or HBA) or expansion expander is physically connected

ID LED

- Works synchronously with front panel ID LED
- Illuminate to identify the chassis

ID button

- Works synchronously with front panel ID button
- Press to toggle the ID LED ON/OFF

UART Console

- The RS-232 port on the Bridge Expander module provides a serial connection for users to manage the JBOD system with terminal application such as Tera Term, Hyper Term...etc. To manage the JBOD system through the serial port, configure the terminal console as per the settings below to connect it.

<i>Parameter</i>	<i>Value</i>
Baud Rate	115200
Data	8 bit
Parity	None
Stop Bit	1 bit
Flow Control	None

Ethernet

- Support 10M/100M/1G bps ethernet PHY
- Support TCP/IP protocol
- Support Telnet CLI
- Support Webpages (http). IP address could be check from CLI then view the webpages for system information on a web browser. Figure 9-12 are the examples of the web pages.


RJ-472

Version
System
Network
HardDisk

Management Board

Model	RJ-472
Board ID	RJ-472 Bridge(S)
Serial Number	14222800380019
SAS Address	5FAE190A_000002FF
MAC Address	FAE190.00.02.FF
Hardware Version	1.0
Firmware Version	3.0.1.0
MFG Version	3.0.1.0
Build Date	Sep 20 2022 10:20:12

Enclosure

Enclosure Height	4U
Bay Number	72
HDD Type	3.5"

Expander 1 (HDD 1-24)

FIGURE 9 VERSION PAGE


RJ-472

Version
System
Network
HardDisk

Temperature Status ^(C)

Bridge Die	40.0
Edge 1 Die	46.0
Edge 2 Die	45.0
Edge 3 Die	46.0
Middle Plane Left	27.7
Middle Plane Right	26.5
Backplane 3 Left	21.5
Backplane 3 Right	25.0
Backplane 2 Left	22.5
Backplane 2 Right	26.5
Backplane 1 Left	22.2
Backplane 1 Right	25.7
Front Panel Left	22.2
Front Panel Right	22.5

Voltage Status ^(V)

PDB 3.3V	3.4
PDB 5V	5.1

FIGURE 10 SYSTEM PAGE



Version

System

Network

HardDisk

Network Status

Physical Address	fa:e1:90:00:02:ff
Ethernet Link Status	Up
Ethernet Link Speed	1000 Mbps
Ethernet Link Duplex Mode	Full
DHCP Enabled	No
AUTOIP Enabled	No
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Default Gateway	192.168.1.254
Host Name	CUB_fa:e1:90:0:2:ff
VLAN Enabled	No
VLAN CFI/PCP/ID	0/6/ffe

FIGURE 11 NETWORK PAGE



Version

System

Network

HardDisk

Disk Slot Status

Bay#	ExpanderID	Link	SAS Address	Disk Type
1	Edge1	12G	5000C500_94D5CA02	SAS
2	Edge1	12G	5000C500_94D5D01E	SAS
3	Edge1	12G	5000C500_94D5D7AE	SAS
4	Edge1	12G	5000C500_94D5D44A	SAS
5	Edge1	12G	5000C500_94D5C8BE	SAS
6	Edge1	12G	5000C500_94D5C7E6	SAS
7	Edge1			
8	Edge1	12G	5000C500_94D5D54E	SAS

FIGURE 12 HARD DISK PAGE

3.5 Edge Expander Module




FIGURE 13 EDGE EXPANDER MODULE

This edge expanders are connected to the bridge expander module by internal SFF-8643 cables. they are controlled by bridge expander. User may manage it through bridge CLI interface (ethernet or RS-232).

Host port (SFF-8643)

- Internal uplink port
- There are 2 ports (Host1 and Host2) connecting to middle plane. Host1 port must connect to middle plane CN6 and Host2 must connect to middle plane CN7.

Expansion port (SFF-8643)

- Not applicable

4 Command Line Interface (CLI)

The RJ-472-08 system provide flexible and useful commands to monitor and manage hard disk, expanders and backplane system. Users can use telnet or console applications to manage the system with CLI commands.

4.1 help

List all command list and the usage

Syntax

```
help [Command]
- X means a mandatory argument described as x
- [X] means an optional argument
- <X> means replace argument with value
- X(D) means a decimal value
- X(H) means a hexadecimal value
- X(*) means special formatting is specified
- X(s) means a decimal value in seconds
- X(ms) means a decimal value in milliseconds
- opt1|opt2|opt3 means literally specify "opt1", "opt2", or "opt3"
- X1 X2 ... means a variable number of arguments
```

Example

```
Bridge >help

=====
Description          Command
=====

Show Sensors         sensor
Remote Command 3     edge3
Remote Command 2     edge2
Remote Command 1     edge1
Remote Command 0     bridge
.
.
.

Bridge >help fd1

=====
Description          Command
=====
```

```
File download          fd1 <BufferID(H)> <Offset(H)> <Erase(*)>
                        - Erase is replaced with "Y" or "N"
```

```
=====
```

4.2 rev

Show vendor ID, product ID, active firmware and firmware version information

Syntax

```
rev
```

Example

```
Bridge >rev

=====
Hardware Revision Information:-
=====

Vendor ID                :IN-WIN
Product ID               :RJ-472 Bridge(P)
Product Revision Level   :Minor = 0x00, Unit = 0x01
Component Type           :Cub
Component ID              :0x0238 (Bond Option :48)
Component Revision Level  :1      (B0)

=====
Firmware Revision Information:-
=====

Active Firmware: Firmware Copy 1

Boot Image:
Revision: 3.0.0.0
Platform Name:  IN-WIN Cub Expander System
Version Name:   SAS35x_FW-03.00.00.00 09/13/21
Firmware Family: 0  OemFamily: 0
Fast Boot: Yes  Image Address: 0x1000000

Firmware Copy 1:
Revision: 3.0.1.0
Platform Name:  IN-WIN Cub Expander System
Version Name:   SAS35x_FW-03.00.01.00 10/20/22
Firmware Family: 0  OemFamily: 0
Fast Boot: Yes  Image Address: 0x10180000

Firmware Copy 2:
Revision: 3.0.0.0
Platform Name:  IN-WIN Cub Expander System
Version Name:   SAS35x_FW-03.00.00.00 10/03/22
Firmware Family: 0  OemFamily: 0
Fast Boot: Yes  Image Address: 0x10300000

=====
```

```

SDK Revision:-
=====
HAL      Revision: 0.16.0.0
SES      Revision: 0.16.0.0
SCE      Revision: 0.16.0.0
Spico Fw Revision: 0x8a69_014f
CSWLib   Revision: 0.0.17.0

=====
Current Toolchain Revision:-

=====
ARM RVDS v.410713

```

4.3 showmfg

Show manufacture configuration version information

Syntax

```
showmfg
```

Example

```

Bridge >showmfg
=====
Manufacturing Image Version Information:-
=====
Product ID :                3
Platform ID:                3
Associated Firmware Revision: 0:11:0:0
Mfg Revision:               3:0:1:0
Product Name:               RJ-472 Bridge(P)
Platform Name:              Expander Cub x48
Mfg Image Creation time stamp: 9/20/22 8:23 (mm/dd/yy hr:min)

```

4.4 sasaddr

display expander's SAS address

Syntax

```
sasaddr
```

Example

```

Bridge >sasaddr

Expander SAS Addresses -

SxP Port 0 SAS Address: 0x5FAE1909100000FD
SxP Port 1 SAS Address: 0x5FAE1909100000FF
SxP Port 2 SAS Address: 0x0000000000000000

```

4.5 date

Show or set current date time. There are no RTC in system. System always starts up at incorrect date. System log will record event with datetime. User can set datetime and broadcast the new value to other expanders by 'date send'

Syntax

```
date [ set <newdate(*)> | send [<SasAddrHi(H)> <SasAddrLow(H)>] |  
                                     recv [<SasAddrHi(H)> <SasAddrLow(H)>] ]  
- no arguments, output local expander date/time and uptime  
- 'set <newdate(*)>' Set local expander date/time using format for <newdate> of  
  YYYYMMDDHHMMSS  
- 'send [sas_addr]' If sas_addr set then set the remote expander's clock using the  
  local expander's current clock value. If sas_addr not specified then set clock  
  for all expanders in the domain.  
- 'recv [sas_addr]' If sas_addr set then fetch the remote expander's current clock  
  and output the result. If sas_addr not specified then get and output the current  
  clock for all expanders in the domain.
```

Example

```
Bridge >date  
Tue Sep 20 09:30:28 2022  
Current expander uptime is 0 days, 0 hours, 35 minutes, 19 seconds  
  
Bridge >date set 20230202103000  
Expander date/time set to Thu Feb  2 10:30:00 2023  
  
Bridge >date send  
Result sending SET TIMESTAMP to 5fae19091000003d: SUCCESS  
Result sending SET TIMESTAMP to 5fae19091000007d: SUCCESS  
Result sending SET TIMESTAMP to 5fae1909100000bd: SUCCESS  
  
Bridge >edge1 date  
>>>edge1:  
  
Thu Feb  2 10:30:42 2023  
Current expander uptime is 0 days, 0 hours, 37 minutes, 48 seconds
```

4.6 showlogs

Show the current system logs

Syntax

```
showlogs [hex|detail|default]
```

Example

```
Bridge >showlogs
<Sep 13 2021 07:53:37.336>:PLATFORM:Firmware initialization started

<Sep 13 2021 07:53:38.682>:EXP:FW COPY 1 REGION: FW image missing

<Sep 13 2021 07:53:38.684>:EXP:FW COPY 2 REGION: FW image missing

<Sep 13 2021 07:53:38.686>:CONFIG:Expander MFG image is not valid

<Sep 13 2021 07:53:37.319>:PLATFORM:Firmware initialization started
...
```

4.7 clearlogs

Clear the system logs

Syntax

```
clearlogs
```

Example

```
Bridge >clearlogs

Bridge >showlogs

Bridge >
```

4.8 showpost

Show POST (Power-On-Self-Test) status of expander

Syntax

```
showpost
```

Example

```
Bridge >showpost

POST status of expander on-chip devices

=====
```

```

On-Chip Device          POST Status

=====

Smart Serial            :PASS
Watchdog Timer          :PASS
Timer 1                 :PASS
Timer 2                 :PASS
Timer 3                 :PASS
Timer 4                 :PASS
PLLS                   :PASS
Interrupt               :PASS
Phy Loopback           :PASS
ISTWI Channel 00       :PASS
ISTWI Channel 01       :PASS
ISTWI Channel 02       :PASS
ISTWI Channel 03       :PASS
ISTWI Channel 04       :PASS
ISTWI Channel 05       :PASS
ISTWI Channel 06       :PASS
ISTWI Channel 07       :PASS
ISTWI Channel 08       :PASS
ISTWI Channel 09       :PASS
ISTWI Channel 10       :PASS
ISTWI Channel 11       :PASS
True Random Num Generator:PASS
Internal RAM Test       :PASS
Forced ECC Error Test   :PASS
SXP Port Buffers Test   :PASS

=====

```

4.9 sesinfo

Display SES-2 devices information

Syntax

```
sesinfo
```

Example

```

Bridge >sesinfo
Show SES Enclosure Elements

Current Fan Level(1~7): 4 4 4 4
Fan01      FanSpd: 8100 SpdCode: 4 Fail: 0
Fan02      FanSpd: 8580 SpdCode: 4 Fail: 0
Fan03      FanSpd: 9420 SpdCode: 5 Fail: 0
Fan04      FanSpd: 7920 SpdCode: 3 Fail: 0
BridgeDie.C Fail: 0 Tempt: 36  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
MP Left.C   Fail: 0 Tempt: 28  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
MP Right.C  Fail: 0 Tempt: 27  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
BP3 Left.C  Fail: 0 Tempt: 28  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
BP3 Right.C Fail: 0 Tempt: 30  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
BP2 Left.C  Fail: 0 Tempt: 29  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
BP2 Right.C Fail: 0 Tempt: 29  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
BP1 Left.C  Fail: 0 Tempt: 26  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
BP1 Right.C Fail: 0 Tempt: 26  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0
FP Left.C   Fail: 0 Tempt: 22  UTWarn: 0  UTFail: 0  OTWarn: 0  OTFail: 0

```

```
FP Right.C      Fail: 0 Tempt: 23      UWarn: 0      UTFail: 0      OTWarn: 0      OTFail: 0
PdbVoltage3.3V 340
PdbVoltage 5V  510
PdbVoltage 12V 1260
MPVoltage 5V    10
MPVoltage 12V   1400
BP3 Voltage 5V  2430
BP2 Voltage 5V  510
BP1 Voltage 5V  510
PowerSupplyElement00 Install: 1, Fail: 0
PowerSupplyElement01 Install: 1, Fail: 0
```

4.10 sensor

Display backplane system sensor information

Syntax

```
sensor
```

Example

```
Bridge >sensor

BP Description: RJ-472,HW:3.0,SW:3.0.0,1
Status: 5(SMBus)      00(BP)  00(FAN)
Expander Installed: 03(MP)      03(BP1) 03(BP2) 03(BP3)
CRPS: 00(Status)      03(Installed)
Temperature: (C)
    ExpDie: 44, 57, 57, 54
    MP: 26.5, 26.7
    BP3: 29.5, 30.7
    BP2: 31.5, 32.0
    BP1: 30.2, 30.2
    FP: 24.7, 26.2
Voltage: (V)
    PDB: 3.4, 5.1, 12.6
    MP: 1.8, 0.1, 14.0
    BP3: 5.1, 5.1
    BP2: 5.1, 5.1
    BP1: 5.1, 5.1
    FP: 5.0
Fan RPM:
    9180, 8760, 7980, 8340,
Fan PWM:
    0, 0, 0, 0, 64, 72, 63, 66,
```




FIGURE 14 SENSOR INFORMATION DETAIL

4.11 hdd

Display 72 bays hard disk PHY information

Syntax

```
hdd
```

Example

Bridge >hdd															
HDD No	DEV TYPE	PHY NLR	PHY CNT	PHY CNG	ATTACHED	SAS ADDR	ROUTE TYPE	ZONE GRP	ZONE CTRL	CONN TYPE	CONN INDX	CONN ELEM	CONN PHY	CONN LINK	MAP PHY ID
1	END	12G	0x03	5000C500_94D5CA01		D	0x01	0x04	0x20	0x01	0x00	0x00	000		
2	END	12G	0x03	5000C500_94D5D01D		D	0x01	0x04	0x20	0x02	0x00	0x00	001		
3	END	12G	0x03	5000C500_94D5D7AD		D	0x01	0x04	0x20	0x03	0x00	0x00	002		
4	END	12G	0x03	5000C500_94D5D449		D	0x01	0x04	0x20	0x04	0x00	0x00	003		
5	END	12G	0x03	5000C500_94D5C8BD		D	0x01	0x04	0x20	0x05	0x00	0x00	004		
6	END	12G	0x03	5000C500_94D5C7E5		D	0x01	0x04	0x20	0x06	0x00	0x00	005		
7	END	12G	0x03	5000C500_94D5C6F1		D	0x01	0x04	0x20	0x07	0x00	0x00	006		
8	END	12G	0x03	5000C500_94D5D54D		D	0x01	0x04	0x20	0x08	0x00	0x00	007		
9	END	12G	0x03	5000C500_94D5C80D		D	0x01	0x04	0x20	0x09	0x00	0x00	008		
10	END	12G	0x03	5000C500_94D5D2CD		D	0x01	0x04	0x20	0x0A	0x00	0x00	009		
11	END	12G	0x03	5000C500_94D5D60D		D	0x01	0x04	0x20	0x0B	0x00	0x00	010		
12	END	12G	0x03	5000C500_94D5D575		D	0x01	0x04	0x20	0x0C	0x00	0x00	011		
13	END	12G	0x03	5000C500_94D5D035		D	0x01	0x04	0x20	0x0D	0x00	0x00	012		
14	END	12G	0x03	5000C500_94D5C915		D	0x01	0x04	0x20	0x0E	0x00	0x00	013		
15	END	12G	0x03	5000C500_94D5D4E1		D	0x01	0x04	0x20	0x0F	0x00	0x00	014		
16	END	12G	0x03	5000C500_94D5D195		D	0x01	0x04	0x20	0x10	0x00	0x00	015		
17	END	12G	0x03	5000C500_94D5D215		D	0x01	0x04	0x20	0x11	0x00	0x00	016		
18	END	12G	0x03	5000C500_94D5CAA1		D	0x01	0x04	0x20	0x12	0x00	0x00	017		
19	END	12G	0x03	5000C500_94D5D72D		D	0x01	0x04	0x20	0x13	0x00	0x00	018		
20	END	12G	0x03	5000C500_94D5D365		D	0x01	0x04	0x20	0x14	0x00	0x00	019		

21	END	12G	0x03	5000C500_94D5CA8D	D	0x01	0x04	0x20	0x15	0x00	020
22	END	12G	0x03	5000C500_94D5CF25	D	0x01	0x04	0x20	0x16	0x00	021
23	END	12G	0x03	5000C500_94D5D21D	D	0x01	0x04	0x20	0x17	0x00	022
24	END	12G	0x03	5000C500_94D5C941	D	0x01	0x04	0x20	0x18	0x00	023
25	END	12G	0x03	5000C500_94D5D6F5	D	0x01	0x04	0x20	0x19	0x00	000
26	END	12G	0x03	5000C500_94D5D7A5	D	0x01	0x04	0x20	0x1A	0x00	001
27	END	12G	0x03	5000C500_94D5CD49	D	0x01	0x04	0x20	0x1B	0x00	002
28	END	12G	0x03	5000C500_94D5CA11	D	0x01	0x04	0x20	0x1C	0x00	003
29	END	12G	0x03	5000C500_94D5D1D1	D	0x01	0x04	0x20	0x1D	0x00	004
30	END	12G	0x03	5000C500_94D5D111	D	0x01	0x04	0x20	0x1E	0x00	005
31	END	12G	0x03	5000C500_94D5CF75	D	0x01	0x04	0x20	0x1F	0x00	006
32	END	12G	0x03	5000C500_94D5CBE9	D	0x01	0x04	0x20	0x20	0x00	007
33	END	12G	0x03	5000C500_94D5D2BD	D	0x01	0x04	0x20	0x21	0x00	008
34	END	12G	0x03	5000C500_94D5D775	D	0x01	0x04	0x20	0x22	0x00	009
35	END	12G	0x03	5000C500_94D5CA45	D	0x01	0x04	0x20	0x23	0x00	010
36	END	12G	0x03	5000C500_94D5CB15	D	0x01	0x04	0x20	0x24	0x00	011
37	END	12G	0x03	5000C500_94D5C76D	D	0x01	0x04	0x20	0x25	0x00	012
38	END	12G	0x03	5000C500_94D5D09D	D	0x01	0x04	0x20	0x26	0x00	013
39	END	12G	0x03	5000C500_94D5D379	D	0x01	0x04	0x20	0x27	0x00	014
40	END	12G	0x03	5000C500_94D5CF71	D	0x01	0x04	0x20	0x28	0x00	015
41	END	12G	0x03	5000C500_94D5D569	D	0x01	0x04	0x20	0x29	0x00	016
42	END	12G	0x03	5000C500_94D5CF79	D	0x01	0x04	0x20	0x2A	0x00	017
43	END	12G	0x03	5000C500_94D5CB01	D	0x01	0x04	0x20	0x2B	0x00	018
44	END	12G	0x03	5000C500_94D5D095	D	0x01	0x04	0x20	0x2C	0x00	019
45	END	12G	0x03	5000C500_94D5D4BD	D	0x01	0x04	0x20	0x2D	0x00	020
46	END	12G	0x03	5000C500_94D5D011	D	0x01	0x04	0x20	0x2E	0x00	021
47	END	12G	0x03	5000C500_94D5CF61	D	0x01	0x04	0x20	0x2F	0x00	022
48	END	12G	0x03	5000C500_94D5D1A1	D	0x01	0x04	0x20	0x30	0x00	023
49	END	12G	0x03	5000C500_94D5CBB9	D	0x01	0x04	0x20	0x31	0x00	000
50	END	12G	0x03	5000C500_94D5D591	D	0x01	0x04	0x20	0x32	0x00	001
51	END	12G	0x03	5000C500_94D5CE01	D	0x01	0x04	0x20	0x33	0x00	002
52	END	12G	0x03	5000C500_94D5CC81	D	0x01	0x04	0x20	0x34	0x00	003
53	END	12G	0x03	5000C500_94D5C9D1	D	0x01	0x04	0x20	0x35	0x00	004
54	END	12G	0x03	5000C500_94D5CC99	D	0x01	0x04	0x20	0x36	0x00	005
55	END	12G	0x03	5000C500_94D5D48D	D	0x01	0x04	0x20	0x37	0x00	006
56	END	12G	0x03	5000C500_94D5CBE1	D	0x01	0x04	0x20	0x38	0x00	007
57	END	12G	0x03	5000C500_94D5CBD9	D	0x01	0x04	0x20	0x39	0x00	008
58	END	12G	0x03	5000C500_94D5CCF1	D	0x01	0x04	0x20	0x3A	0x00	009
59	END	12G	0x03	5000C500_94D5CFC1	D	0x01	0x04	0x20	0x3B	0x00	010
60	END	12G	0x03	5000C500_94D5D725	D	0x01	0x04	0x20	0x3C	0x00	011
61	END	12G	0x03	5000C500_94D5D3B5	D	0x01	0x04	0x20	0x3D	0x00	012
62	END	12G	0x03	5000C500_94D5CBF9	D	0x01	0x04	0x20	0x3E	0x00	013
63	END	12G	0x03	5000C500_94D5D7FD	D	0x01	0x04	0x20	0x3F	0x00	014
64	END	12G	0x03	5000C500_94D5D4C5	D	0x01	0x04	0x20	0x40	0x00	015
65	END	12G	0x03	5000C500_94D5CEED	D	0x01	0x04	0x20	0x41	0x00	016
66	END	12G	0x03	5000C500_94D5CFD1	D	0x01	0x04	0x20	0x42	0x00	017
67	END	12G	0x03	5000C500_94D5CDF9	D	0x01	0x04	0x20	0x43	0x00	018
68	END	12G	0x03	5000C500_94D5CE71	D	0x01	0x04	0x20	0x44	0x00	019
69	END	12G	0x03	5000C500_94D5D735	D	0x01	0x04	0x20	0x45	0x00	020
70	END	12G	0x03	5000C500_94D5CA19	D	0x01	0x04	0x20	0x46	0x00	021
71	END	12G	0x03	5000C500_94D5D5E9	D	0x01	0x04	0x20	0x47	0x00	022
72	END	12G	0x03	5000C500_94D5D761	D	0x01	0x04	0x20	0x48	0x00	023

4.12 console

Switch RS-232 UART control to bridge, edge1, edge2 or edge3 expander.

Syntax

```
console <0|1|2|3>
```

Example

```
Bridge >console 1
Switch Smart Console to Edge1
```

```
Edge1 >
Edge1 >console 0
Switch Smart Console to Bridge

Bridge >
Bridge > console 2
Switch Smart Console to Edge2

Edge2 >
Edge2 >console 0
Switch Smart Console to Bridge

Bridge >
```

4.13 bpsys

Display backplane system control parameters that are saved in persistent storage (flash)

Syntax

```
bpsys
```

Example

```
Bridge >bpsys
BP System NVRAM Config:
  Fan Speed Profile: Normal
  Auto Power UP: 0
  Mute Enable: 0
  Fan Control Temperature Base: 44
  Zone Config: 0 (Disable)

BP System Running Status:
  Test Enable: 0
  ID LED Enable: 0
```

bpsys power <0|1>

set backplane system auto power-on and startup after power suppliers ready. Default value 0 requires users to press power button for more than 3 seconds to power up system.

Syntax

```
bpsys power <0|1>
```

Example

```
Bridge >bpsys power 1
Set Auto Power UP: 1
```

bpsys default <0>

reset backplane system configuration to default

Syntax

```
bpsys default <0>
```

Example

```
Bridge >bpsys default 0
Reset bpsys to default configuration!
Reboot system to use the new setting

Bridge >reset

Performing POST for Smart Serial
...
```

bpsys fan <0|1|2>

Set backplane system fan speed profile mode. There are 3 modes for fan speed profile. Default value is 1 (Normal)

Mode ID	Name	Description
0	Quiet	8 fan RPM levels – 34%, 44%, 54%, 63%, 71%, 79%, 87%, 95%
1	Normal	8 fan RPM levels – 41%, 49%, 57%, 65%, 73%, 81%, 89%, 97%
2	Aggressive	8 fan RPM levels – 45%, 53%, 61%, 69%, 77%, 85%, 93%, 100%

Syntax

```
bpsys fan <0|1|2>
```

Example

```
Bridge >bpsys fan 0
Set Fan Speed Profile: 0
```

bpsys thermal <37~52>

Set maximum temperature (Celsius) for fan speed maximum level control. Default value is 44 (Celsius). Fan controller get thermal sensors' readings in Celsius and use the maximum value to map the SES fan level for PWM(or RPM) control. User can adjust fan speed control level by the command.

Below figure shows “bpsys thermal 42” and “bpsys thermal 45” cases. For example, system set fan speed profile to normal mode and the highest value in system temperature sensors (not including expander die temperature) is 40.1. If configure

“bpsys thermal 42” then the fan speed will reach highest level (97% speed). If configure “bpsys thermal 45” then the fan speed will reach second highest level (89% speed). Because the hard divers may install partial and make cooling airflow too much or less. User can adjust the value to find the efficient fan speed.




FIGURE 15 3 ZONES CONFIGURATION

Syntax

```
bpsys thermal <37~52>
```

Example

```
Bridge >bpsys thermal 45
Set Fan Control Max Temperature (37C~52C): 45
```

bpsys zone <0|1>

Set PHY zone mode. There are 2 zone mode (0 - disable or 1 - enable). Default (0) is zone disabled. Refer to Figure 16 for enable mode (3 zones – zone1 is bay1-24, zone2 is bay25-48, zone3 is bay49-72)

3 Zones Configuration – 24/24/24




FIGURE 16 3 ZONES CONFIGURATION

Syntax

```
bpsys zone <0|1>
```

Example

```
Bridge >bpsys zone 1
Set Zone Profile: 1
```

bpsys mute <0|1>

Set backplane system buzzer to mute mode. Default (0) is to enable beeping when system occurs some errors.

Syntax

```
bpsys mute <0|1>
```

Example

```
Bridge >bpsys mute 1
Set Mute Enable: 1
```

bpsys id <0|1>

Turn backplane system ID LED on or off. The value is not saved to storage. Default (0) is to turn off ID LED. This command enable user to turn on ID LED from remote.

Syntax

```
bpsys id <0|1>
```

Example

```
Bridge >bpsys id 1
ID LED Enable: 1
```

bpsys test <0|1>

Set backplane system to test mode that blinks all LEDs and play buzzer for test. The value is not saved to storage. Default (0) is to quit the test mode.

Syntax

```
bpsys test <0|1>
```

Example

```
Bridge >bpsys test 1
Test Enable: 1
```

bpsys reset <1>

Make backplane system to reset all backplanes, expanders, front panel, middle plane and PDB. The command will power down all expanders, front panel, BP1, BP2, BP3. Then reset middle plan and PDB modules. System will then power on BP1, BP2, BP3 and front panel in few seconds, and wait another few seconds to power on expanders and HDDs.

Syntax

```
bpsys reset <1>
```

Example

```
Bridge >bpsys reset 1
Reset MCU System

Bridge >
Performing POST for Smart Serial
...
```

4.14 ipconfig

Show or configure network interface IP address for RJ-460-08 bridge board.

ipconfig [verbose]

Display bridge expander module ethernet port configuration that are saved in persistent storage (flash). Default setting is static IP address (192.168.100.1).

Syntax

```
ipconfig [verbose]
```

Example

```
Bridge >ipconfig

=====
Physical Address . . . . . : FA-E1-90-00-02-FF
DHCP Enabled . . . . . : No
AUTOIP Enabled . . . . . : No
IP Address . . . . . : 192.168.1.1
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.1.254
Ethernet Link Status . . . . . : Up
Ethernet Link Speed . . . . . : 1000 Mbps
Ethernet Link Duplex Mode . . . . . : Full
=====

Bridge >ipconfig verbose

=====
Physical Address . . . . . : FA-E1-90-00-02-FF
DHCP Enabled . . . . . : No
AUTOIP Enabled . . . . . : No
IP Address . . . . . : 192.168.1.1
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.1.254
Ethernet Link Status . . . . . : Up
Ethernet Link Speed . . . . . : 1000 Mbps
Ethernet Link Duplex Mode . . . . . : Full
Ethernet speed/duplex initial setting: 0
Host Name . . . . . : CUB_fa:e1:90:0:2:ff
VLAN Enabled . . . . . : No
VLAN CFI/PCP/ID . . . . . : 0/6/ffe
WakeLan Magic Packet Wakeup Enabled : No
WakeLan Unicast Packet Wakeup Enabled: No
=====
```

ipconfig dhcp

configure ethernet port IP address to DHCP mode.

Syntax

```
ipconfig dhcp
```

Example

```
Bridge >ipconfig dhcp

Please reboot for new setting

Bridge >reset

...
Bridge >ipconfig

=====
Physical Address . . . . . : FA-E1-90-00-15-FF
DHCP Enabled . . . . . : Yes
AUTOIP Enabled . . . . . : No
IP Address . . . . . : 192.168.173.153
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.173.250
Ethernet Link Status . . . . . : Up
Ethernet Link Speed . . . . . : 1000 Mbps
Ethernet Link Duplex Mode . . . . . : Full
=====
```

`ipconfig static <ip_addr> <netmask> <gateway>`

Configure ethernet port to static mode and assign the IP address, netmask and gateway.

Syntax

```
ipconfig static <IP_addr> <Netmask> <Gateway>
```

Example

```
Bridge >ipconfig static 192.168.1.1 255.255.255.0 192.168.1.254

Please reboot for new setting

Bridge >reset

...
Bridge >ipconfig

=====
Physical Address . . . . . : FA-E1-90-00-15-FF
DHCP Enabled . . . . . : No
AUTOIP Enabled . . . . . : No
IP Address . . . . . : 192.168.1.1
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.1.254
=====
```

```

Ethernet Link Status . . . . . : Up
Ethernet Link Speed . . . . . : 1000 Mbps
Ethernet Link Duplex Mode . . . . . : Full
=====

```

ipconfig auto

Configure ethernet port to auto IP mode.

Syntax

```
ipconfig auto
```

Example

```

Bridge >ipconfig auto

Please reboot for new setting

Bridge >reset

...
Bridge >ipconfig

=====
Physical Address . . . . . : FA-E1-90-00-15-FF
DHCP Enabled . . . . . : No
AUTOIP Enabled . . . . . : Yes
IP Address . . . . . : 169.254.125.78
Subnet Mask . . . . . : 255.255.0.0
Default Gateway . . . . . : 0.0.0.0
Ethernet Link Status . . . . . : Up
Ethernet Link Speed . . . . . : 1000 Mbps
Ethernet Link Duplex Mode . . . . . : Full
=====

```

ipconfig dhcp_auto

Configure ethernet port to DHCP and auto IP mode that system will try to get IP address from DHCP. If no DHCP server exist, system will use auto IP mode.

Syntax

```
ipconfig dhcp_auto
```

Example

```

Bridge >ipconfig dhcp_auto

Please reboot for new setting

```

```
Bridge >reset

...
Bridge >ipconfig

=====
Physical Address . . . . . : FA-E1-90-00-15-FF
DHCP Enabled . . . . . : Yes
AUTOIP Enabled . . . . . : Yes
IP Address . . . . . : 192.168.173.156
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.173.250
Ethernet Link Status . . . . . : Up
Ethernet Link Speed . . . . . : 1000 Mbps
Ethernet Link Duplex Mode . . . . . : Full
=====
```

4.15 fdl

fdl <0|1> <0> <y>

Download firmware or manufacture config (MFG) image from console or telnet. The download protocol is XMODEM, refer to Figure 17




FIGURE 17 FIRMWARE UPGRADE BY XMODEM

Syntax – Download Firmware

```
fdl 0 0 y
```

Syntax – Download MFG

```
fdl 1 0 y
```

Example

```
Bridge >fdl 0 0 y
Please Use XModem Protocol for File Transmission.

Use Q Or q to quit Download before starting XModem.

Received 612736Bytes
Buffer Download Complete
Start downloading to Edge Expanders ...
Edge1 Download Successfully!
Edge2 Download Successfully!

Bridge >fdl 1 0 y
Please Use XModem Protocol for File Transmission.

Use Q Or q to quit Download before starting XModem.

Received 49152Bytes
Buffer Download Complete
Start downloading to Edge Expanders ...
Edge1 Download Successfully!
Edge2 Download Successfully!
```

4.16 tftpd32

tftpd32 <0|1> <0> <y> <tftp_server_ip> <filename>

To upgrade firmware through TFTP, open a TFTP server (Figure 18) on your console host and specify the path in TFTP server to the directory where the firmware is stored. Please be sure the TFTP server is reachable to the JBOD system.




FIGURE 18 TFTP SERVER FOR UPGRADE

Syntax – Download Firmware through TFTP

```
tftpfdl 0 0 y <tftp_server_ip> <fw_filename>
```

Syntax – Download MFG through TFTP

```
tftpfdl 1 0 y <tftp_server_ip> <mfg_filename>
```

Example

```
Bridge >tftpfdl 0 0 y 192.168.173.139 RJ472-3.0.1.fw  
  
Received 612776Bytes  
Firmware Download Complete  
  Start downloading to Edge Expanders ...  
  Edge1 Download Successfully!  
  Edge2 Download Successfully!
```